

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026

Purpose

This document describes how to monitor an AKCP sensorProbe2 device with Nagios XI to be alerted when temperature, humidity, or other environmental variables exceed specific thresholds.

This document outlines how to monitor the Dual Temperature/Humidity sensor connected to the sensorProbe2, however various AKCP intelligent sensors can be connected via the RJ45 connectors to the sensorProbe devices and then monitored in Nagios XI in a similar manor. This document will demonstrate how to monitor the device using Active or Passive monitoring.

The sensorProbe2, sensorProbe4, sensorProbe8 and Probe8-X20 are intelligent devices for monitoring environmental variables and notify you through SNMP alerts to prevent any issues when environmental variables change.

Target Audience

This document is intended for use by Nagios XI Administrators who want to monitor an AKCP sensorProbe2 Dual Temperature/Humidity Sensor device via SNMP.

Prerequisites For Monitoring A Device Passively Via SNMP Traps

It is possible to monitor your AKCP sensorProbe2 actively or passively within your Nagios XI system. Active checks do not require any prerequisites for your Nagios XI system. Passive checks require you to set up your Nagios XI system to receive SNMP traps.

This document assumes you have already set your Nagios XI system to receive SNMP traps. If you have not already done this, please refer to the following documentation:

[Integrating SNMP Traps With Nagios XI](#)

Download The AKCP MIB Into Nagios XI


Monitoring via SNMP requires the AKCP MIB definition.

1. The first step is to download and install the correct MIB file. You can download the MIB for an AKCP device from the link below:

http://www.akcp.com/wp-content/uploads/2010/04/akcp_mib211210.zip

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026

2. Once the MIB is downloaded, you need to unzip the `akcp_mib211210.zip` file which will provide you with the `akcp.mib` file that will be used in the next step.
3. Next, you will install the `akcp.mib` from the Nagios XI Web interface by navigating to **Admin > System Extensions > Manage MIBs**.




4. Click the **Browse** button and locate the `akcp.mib` file.



5. Check the **Process** trap check box then click the **Upload MIB** button.

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026





You will receive a message to say the MIB file was successfully processed.

6. You can also verify that your MIB was processed by Nagios XI, on your Nagios server check to see that the `akcp.mib` file is in the `/usr/share/snmp/mibs/` directory. In addition to this an extensive amount of SNMP Trap EVENTS will be put into the `/etc/snmp/snmpd.conf` file (these are for passive monitoring).

Run The SNMP Wizard To Set Up Active Checks

To begin using the SNMP wizard navigate via the top menu bar to **Configure > Run** a configuring wizard and select the **SNMP wizard**. In the following screenshot you can see how the search field allows you to quickly find a wizard.

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026



1. In **Step 1** enter the address for the AKCP sensor in the Device Address box and click Next.
2. In **Step 2** you are required to enter a SNMP Community string (it is not suggested to use the default of "public") and the SNMP Version. For this example, we used version 2.

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026

SNMP Configuration Wizard Step 2

Device Details

Device Address: 192.168.5.199

Host Name: 192.168.5.199

SNMP Settings

SNMP Version: 2c

SNMP Port: 161

SNMP Version Settings

SNMP Community: public

SNMP Services

Specify any OIDs you would like to monitor via SNMP. Sample entries have been provided as examples

OID	Display Name	Data Label	Data Units (Optional)	Match Type	Warning Range	Critical Range	String To Match	MIB To Use
<input type="checkbox"/> 3.6.1.4.1.3854.1.2.2.1.16	Temp Sensor 1	Temp	Deg. F	Numeric	60,85	60,85		akcp.mib
<input type="checkbox"/> 3.6.1.4.1.3854.1.2.2.1.17	Humidity Sensor 1	Humidity	%	Numeric	15,45	10,50		akcp.mib

Add Row | Delete Row

< Back Next > Cancel

3. Finally, you will need to enter information into the SNMP Service section. Create a row for each sensor. For example, the SNMP OID for the temperature sensor on RJ45#1 is:

1.3.6.1.4.1.3854.1.2.2.1.16.1.3.0

The SNMP OID for the humidity sensor on RJ45#1 is:

1.3.6.1.4.1.3854.1.2.2.1.17.1.3.0

If you added an additional sensor in the second port (2) their OID would be very similar to the temperature and humidity sensors. You will have to change 0 (zero) at the end of the OID to 1 (one). These sensors would be added to the SNMP service section as:

1.3.6.1.4.1.3854.1.2.2.1.16.1.3.1 and 1.3.6.1.4.1.3854.1.2.2.1.17.1.3.1

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026

4. Continue to fill in the remaining fields in the SNMP Service section. It is important to note the warning and critical values in this example are set up as ranges. A critical alert occurs when the temperature is outside of the range 60-85 degrees. Finally, select the check boxes next to the temperature sensor and humidity sensor OIDs and click **Next**.
5. Click **Next** and then complete the wizard by choosing the required options in **Step 3 - Step 5**. To finish, click on **Finish** in the last step of the wizard. This will create new host and services and begin monitoring.

Once the wizard applies the configuration, click the View status details for your AKCP sensor link to see the new service that was created.

Service Status for this Host						Last updated: 2024-12-04 18:06:15
Service	Status	Duration	Attempt	Last Check	Status Information	
Humidity Sensor 1	 Warning	18m 35s	1/5	2024-12-04 16:05:08	SNMP WARNING = Humidity "49%"	
Temp Sensor 1	 Critical	5d 17h 19m 21s	5/5	2024-12-04 16:07:32	SNMP CRITICAL = Temp "78" F	

This completes configuring Nagios XI to monitor the AKCP sensorProbe2 using Active monitoring.

Configuring The Sensor to Send Passive Checks Via SNMP To Nagios XI

Sending Passive Checks to Nagios requires some set up on the AKCP sensorProbe2. To do this we need to log into the AKCP Web interface by entering the IP address into your browser. The web interface will require you to enter your user account and password.

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026

1. First you will want to set up your check thresholds on each sensor, and for this example we will set up the Temperature sensor on Port 1. Click on the **Sensor** tab, then under **Environmental** select **Temperature**, and finally select the **Temperature** sensor on port 1. From this screen enter your threshold information for critical events.



The screenshot displays the configuration interface for the AKCP sensorProbe2 v2.0. It features a blue header with the title and three tabs: Traps, Mail, and Network. The 'Traps' tab is active, showing 'Trap Settings'. Under 'Trap 1', the following settings are visible: 'Send Trap' is set to 'On', 'Destination IP' is '192.168.4.114', 'Community' is 'nagiosprivate', 'Send Keep Alive Trap' is 'Off', and 'Keep Alive Trap Resend Interval (mins)' is '3600' (2 day 12 hrs). Below these are 'Save' and 'Reset' buttons. 'Trap 2' settings include: 'Send Trap' is 'On', 'Destination IP' is '192.168.4.127', 'Community' is 'nagiosprivate', and 'Resend Warning and Error Traps' is 'On' with a 'Resend Interval (secs)' of '3600' (1 hrs, 0 secs). Again, 'Save' and 'Reset' buttons are present. At the bottom, a copyright notice reads: '©1991 - 2013 AKCess Pro Limited All rights reserved.'


6. Next click on the **Traps** tab to enter pertinent information for sending SNMP traps to Nagios XI. Enter the **IP of your Nagios server for the Destination IP**.
7. Next enter a **community string**. It is always a good idea to change the default community string from `public` to something else.
8. Click on the **Save** button and you are done with the set up required for the AKCP sensor.

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026


Configuring Nagios XI to Receive Passive Checks

Once you have your Nagios server set up to receive SNMP Traps as outlined in the prerequisite section, you will be able to set up Nagios XI to receive passive checks from the AKCP sensorProbe2.


1. To begin using the SNMP Trap wizard navigate via the top menu bar to **Configure > Run a configuring wizard** and select the **SNMP Trap wizard**. In the following screenshot you can see how the search field allows you to quickly find a wizard.



How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026



2. **Step 1** there are no options, click **Next**.



3. In **Step 2** select the host you wish to enable SNMP traps for and click **Next**.

- a. Click **Next** and then complete the wizard by choosing the required options in **Step 3 - Step 5**. To finish, click on **Finish** in the last step of the wizard. This will create new host and services and begin monitoring.

How To Monitor AKCP SensorProbe2 In Nagios XI 2024 And 2026

- Once the wizard applies the configuration, click the **View status details** for your AKCP sensor link to see the new service that was created.

Service Status for this Host						Last updated: 2024-12-04 18:06:15
Service	Status	Duration	Attempt	Last Check	Status Information	
Humidity Sensor 1	 Warning	18m 35s	1/5	2024-12-04 16:05:08	SNMP WARNING = Humidity "49" %	
SNMP Traps	 OK	12h 54m 59s	5/5	2024-12-04 16:08:45	Waiting for trap ...	
Temp Sensor 1	 Critical	5d 17h 19m 21s	5/5	2024-12-04 16:07:32	SNMP CRITICAL = Temp "78" F	

This completes configuring Nagios XI to monitor the AKCP sensorProbe2 using Passive monitoring.

Troubleshooting

If for some reason you do not see SNMP traps changing the status of your service check in Nagios XI, check your Unconfigured Objects page (accessed via **Admin > Monitoring Config > Unconfigured Objects**).

Also, reviewing the logs created by SNMPTT can help you troubleshoot the issue as well.

```
tail /var/log/snmpptt/snmpptt.log
```

```
tail /var/log/snmpptt/snmppttunknown.log
```

```
tail /var/log/messages
```

More Information

[Using Configuration Wizards](#)

Finishing Up

This completes the documentation on how to monitor AKCP SensorProbe2 in Nagios XI 2024. If you have additional questions or other support-related questions, please visit us at our Nagios Support Forum, Nagios Knowledge Base, or Nagios Library:

[Visit Nagios Support Forum](#)

[Visit Nagios Knowledge Base](#)

[Visit Nagios Library](#)